



1

2

3

1 für Navi, Tel. und sw

2 4 6 8 10 14 16 18 20 22 23

1 3 5 7 9 11 12 13 15 17 19 21 23

1-N/C 13-NAV-

2-N/C 14-NAV+

3-SPEED-SIQ 15-GND

4-IMMOBIL 16-N/C

5-ILL-CONT 17-N/C

6-TEL-ON 18-N/C

7-TEL- 19-BUS-

8-TEL+ 20-BUS+

9-GND 21-GND

10-N/C 22-GND

11-N/C 23-BUS-

12-N/C 24-BUS+

2 Lautsprecher und Stromversorgung Audioanlage

26 28 30 34 36

25 27 29 31 32 33 35

25-ILL 31-FR-

26-ACC 32-FR+

27-B/U 33-RL-

28-B/U 34-RL+

29-FL- 35-RR-

30-FL+ 36-RR+

3 CD-wechsler

38 40 46 48

37 39 41 42 43 44 45 47

37-CHQ L- 43-N/C

38-CHQ L+ 44-REQ

39-CHQ R- 45-CHQ-H/U

40-CHQ R+ 46-H/U-CHQ

41-GND 47-N/C

42-GND 48-N/C